



ITEM# 58005

1521 E Third Street, Charlotte, NC 28204 | 1-800-633-3914 | howco.com

HOWCOSM POLISH BOND™ 2.0

# OF DROPS		RATIO	SUGGESTED USAGE RANGE
3		178 : 1	Tough Cleaning
2		272 : 1	Normal Cleaning
1		557 : 1	Easy Cleaning



ITEM# 58005

HOWCOSM POLISH BOND™ 2.0

1521 E Third Street, Charlotte, NC 28204 | 1-800-633-3914 | howco.com

1. Rinse vial three times with sample to be tested. **Fill vial to 25 mL.**



2. **Add 3 drops Phenolphthalein (R-0638)** and swirl to mix. The sample will remain **CLEAR.**



3. While holding the bottle vertically, **Add Standard Alkali (R-0656)** 1 drop at a time. **BEGIN COUNTING NUMBER OF DROPS.** Swirl between each drop.



4. Stop when the color changes from **CLEAR** to **PINK** and remains for **30 seconds.**



NOTE the number of drops and refer to the titration card for recommendations.