

titration card



ITEM# 58010

1521 E Third Street, Charlotte, NC 28204 | 1-800-633-3914 | howco.com

HOWCOSM SEALER 2.0 - T

# OF DROPS	RATIO	SUGGESTED USAGE RANGE
12	500 : 1	Drying Agent
10	625 : 1	Drying Agent
8	750 : 1	Drying Agent



ITEM# 58010

HOWCOSM SEALER 2.0 - T

1521 E Third Street, Charlotte, NC 28204 | 1-800-633-3914 | howco.com

1. Rinse vial three times with sample to be tested. Fill vial to **10 mL**.



2. Add 0.5 mL Complexing Reagent (R-0950) and swirl to mix. The sample should remain **CLEAR**.



3. Add 2 drops of Toluidine Blue Indicator (R-0881) and swirl to mix. The sample should turn **BLUE**.



4. Add QAC Titrating Solution (R-0884) - 1 drop at a time. BEGIN COUNTING NUMBER OF DROPS. While holding the bottle vertically, swirl between each drop. The color will change from **BLUE** to **PURPLE**.



****NOTE # of drops and see reverse side for recommendations.**